

Refacing Ordering Guidelines

You have these conditions:



NOTE 1: Our maximum door size height is 63", for sizes larger you will need to order 2 doors.
NOTE 2: Your doors will be attached together using our mending kit.

Determine your door front sizes:

1. Download our helpful form to record your information the same way our website will ask for it.
2. Calculate your hinge overlay using the formula on the right to determine if it's one of the Available Hinge Overlays.

If your hinge overlay is any of the Available Hinge Overlays:

- Measure your existing door to the closest 1/16" (0.0625"). Measure width first, then height.
- Divide the height into 2 doors less than 63" each.

If your hinge overlay is not any of the Available Hinge Overlays or you have No Door, we suggest you use a 1/2" overlay on your replacement door:

- Measure your cabinet opening to the closest 1/16" (0.0625").
- Add 1" to the cabinet opening width and to the opening height.
- Divide the height into 2 doors less than 63" each.

3. Write the dimensions of the doors you need on the measurement form.

Calculate Your Hinge Overlay	
$\left(\frac{\text{Door Width}}{2}\right) - \left(\frac{\text{Opening Width}}{2}\right) =$	

Available Hinge Overlays	
1/2"	0.5"
3/4"	0.75"
1"	1.00"
1-1/4"	1.25"
1-3/8"	1.375"

What to order:

1. Order 2 doors to cover opening with the dimensions determined above.
2. Order the accessory item: "I-O295 Mending Plate to Join Doors, with Screws."